

ECBC

Spore Size Comparison Between Several Bacillus Species

**Ruben O. Zandomeni¹, Joseph E. Fitzgibbon², Monica
Carrera¹, Edward Stuebing², James E. Rogers², and
Jose-Luis Sagripanti²**

**¹GeoCenters, Inc. and ²RDECOM, Edgewood Chemical
and Biological Center, US Army, Aberdeen Proving
Ground, MD 21010**



Report Documentation Page				Form Approved OMB No. 0704-0188	
Public reporting burden for the collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington VA 22202-4302. Respondents should be aware that notwithstanding any other provision of law, no person shall be subject to a penalty for failing to comply with a collection of information if it does not display a currently valid OMB control number.					
1. REPORT DATE 01 OCT 2005		2. REPORT TYPE N/A		3. DATES COVERED -	
4. TITLE AND SUBTITLE Spore Size Comparison Between Several Bacillus Species				5a. CONTRACT NUMBER	
				5b. GRANT NUMBER	
				5c. PROGRAM ELEMENT NUMBER	
6. AUTHOR(S)				5d. PROJECT NUMBER	
				5e. TASK NUMBER	
				5f. WORK UNIT NUMBER	
7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) GeoCenters, Inc.				8. PERFORMING ORGANIZATION REPORT NUMBER	
9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES)				10. SPONSOR/MONITOR'S ACRONYM(S)	
				11. SPONSOR/MONITOR'S REPORT NUMBER(S)	
12. DISTRIBUTION/AVAILABILITY STATEMENT Approved for public release, distribution unlimited					
13. SUPPLEMENTARY NOTES See also ADM001851, Proceedings of the 2003 Joint Service Scientific Conference on Chemical & Biological Defense Research, 17-20 November 2003. , The original document contains color images.					
14. ABSTRACT					
15. SUBJECT TERMS					
16. SECURITY CLASSIFICATION OF:			17. LIMITATION OF ABSTRACT UU	18. NUMBER OF PAGES 31	19a. NAME OF RESPONSIBLE PERSON
a. REPORT unclassified	b. ABSTRACT unclassified	c. THIS PAGE unclassified			

Introduction

- **GOALS** - Better understand properties of simulants vs. agents. Provide data to help choose appropriate simulants and surrogates for specific tasks.
- **METHOD** - Compare properties of simulants to those of the agents.
- **FACILITY**
Microbiology
Team
BSL3
Laboratory



ECBC

Properties (Non-Medical)

- **Spore Size – length, width, aspect ratio**
- **Spore Density**
- **Effect of decon agents**
- **Fluorescence spectra**
- **Effect of UV radiation**



ECBC

Spore Size

- Important to design and development of samplers and detectors
- Published spore sizes - spores produced under different conditions for each species without extensive comparisons, size distributions or ranges.
- Systematic comparison of the size of *B.anthraxis* spores to size of other *Bacillus* spores (simulants/surrogates) - all spores produced under the same conditions.





ECBC

Methods

- Prepared spores of *B.anthraxis* and other *Bacillus* species, including some common simulants/surrogates.
- Spores were fixed, negatively stained and imaged by TEM.
- Measurements of 100 spores (length, width, aspect ratio).
- Produced distributions.



B. globigii SB512 (*B. atrophaeus*)



- **Length**


Mean $1.22 \pm 0.12 \mu\text{m}$

Range 0.91-1.90 μm

- **Width**


Mean $0.65 \pm 0.05 \mu\text{m}$

Range 0.56-0.80 μm



ECBC

B. subtilis 1031



- **Length**



Mean $1.07 \pm 0.09 \mu\text{m}$

Range $0.87\text{-}1.41 \mu\text{m}$

- **Width**


Mean $0.48 \pm 0.03 \mu\text{m}$

Range $0.41\text{-}0.58 \mu\text{m}$



ECBC

B. cereus ATCC 10702



- **Length**



Mean $1.55 \pm 0.16 \mu\text{m}$

Range 1.21-2.00 μm

- **Width**


Mean $0.90 \pm 0.07 \mu\text{m}$

Range 0.76-1.14 μm



ECBC

B. megaterium WW-15-4900



- **Length**



Mean $1.60 \pm 0.16 \mu\text{m}$

Range 1.28-2.04 μm

- **Width**


Mean $0.84 \pm 0.07 \mu\text{m}$

Range 0.70-1.05 μm





ECBC



B. mycoides ATCC 10206



- **Length**
Mean $1.85 \pm 0.21 \mu\text{m}$
Range 1.33-2.44 μm
- **Width**
Mean $0.91 \pm 0.07 \mu\text{m}$
Range 0.65-1.04 μm



B. anthracis (Sterne)



- **Length**


Mean $1.53 \pm 0.15 \mu\text{m}$

Range 1.19-1.92 μm

- **Width**



Mean $0.88 \pm 0.06 \mu\text{m}$

Range 0.71-1.09 μm



ECBC

B. anthracis (Δ -Sterne)



- **Length**


Mean $1.56 \pm 0.16 \mu\text{m}$

Range 1.23-2.05 μm

- **Width**



Mean $0.82 \pm 0.06 \mu\text{m}$

Range 0.68-0.98 μm



ECBC

B. anthracis (Albia)



- **Length**


Mean $1.43 \pm 0.14 \mu\text{m}$

Range 1.22-1.79 μm

- **Width**


Mean $0.87 \pm 0.07 \mu\text{m}$

Range 0.71-1.03 μm



ECBC

B. anthracis (NCTC 1087)



- **Length**



Mean $1.68 \pm 0.19 \mu\text{m}$

Range 1.23-2.08 μm

- **Width**




Mean $0.89 \pm 0.06 \mu\text{m}$

Range 0.76-1.09 μm




ECBC

B. anthracis (NCTC 1928)




B. anthracis (LA1)




ECBC

Aspect Ratio (L/W) of Bacillus spores




B. globigii

Mean 1.85 +/- 0.19
Range 1.43-2.39




B. a. Sterne

Mean 1.75 +/- 0.20
Range 1.33-2.20



B. subtilis

Mean 2.23 +/- 0.25
Range 1.63-2.95



B. a. NCTC 1087

Mean 1.91 +/- 0.23
Range 1.37-2.45



ECBC


Comparison of *B. anthracis* with other *Bacillus* species

	Length (μm)	Width (μm)
<i>B. anthracis</i> Albia	1.43 +/- 0.14	0.87 +/- 0.07
<i>B. anthracis</i> 1087	1.68 +/- 0.19	0.89 +/- 0.06
<i>B. anthracis</i> Sterne	1.53 +/- 0.15	0.88 +/- 0.06
<i>B. anthracis</i> D-Sterne	1.56 +/- 0.16	0.82 +/- 0.06
<i>B. globigii</i>	1.22 +/- 0.12	0.65 +/- 0.05
<i>B. subtilis</i>	1.07 +/- 0.09	0.48 +/- 0.03
<i>B. cereus</i>	1.55 +/- 0.16	0.90 +/- 0.07
<i>B. megaterium</i>	1.60 +/- 0.16	0.84 +/- 0.07
<i>B. mycoides</i>	1.85 +/- 0.21	0.91 +/- 0.07




ECBC

B.a. 1087 vs. B. g. (Length)




ECBC

B.a. 1087 vs. B. g. (Width)




ECBC

B.a. Albia vs. *B. g.* (Length)




ECBC

B.a. Albia vs. B. g. (Width)




ECBC


B.a. 1087 vs. *B. subtilis* (Length)



B.a. 1087 vs. *B. subtilis* (Width)




B.a. 1087 vs. *B. cereus* (Length)





ECBC

B.a. 1087 vs. *B. cereus* (Width)



ECBC

B. globigii SB512 (*B. atrophaeus*)



- Length


Mean $1.27 \pm 0.10 \mu\text{m}$

Range 1.04-1.61 μm

- Width



Mean $0.67 \pm 0.07 \mu\text{m}$

Range 0.50-0.94 μm



ECBC

B. subtilis 1031



- **Length**


Mean $1.14 \pm 0.07 \mu\text{m}$

Range 1.04-1.28 μm

- **Width**



Mean $0.54 \pm 0.04 \mu\text{m}$

Range 0.46-0.69 μm



ECBC

B. anthracis (Δ -Sterne)



- **Length**


Mean $1.48 \pm 0.07 \mu\text{m}$

Range 1.37-1.71 μm

- **Width**

Mean $0.89 \pm 0.05 \mu\text{m}$

Range 0.75-1.00 μm



ECBC

Comparison of Measurements by TEM vs. OM

		Length	Width
<i>B. globigii</i>	TEM	1.22 +/- 0.12	0.65 +/- 0.05
	OM	1.27 +/- 0.10	0.67 +/- 0.07
<i>B. subtilis</i>	TEM	1.07 +/- 0.09	0.48 +/- 0.03
	OM	1.14 +/- 0.07	0.54 +/- 0.04
<i>B. anthracis</i> (d-Sterne)	TEM	1.56 +/- 0.16	0.82 +/- 0.06
	OM	1.48 +/- 0.07	0.89 +/- 0.05



CONCLUSIONS

- Systematic comparison of spore properties of several *Bacillus* species.
- Compared spore size properties of 6 species of *Bacillus* by TEM.
- *B. anthracis* spores are significantly larger than spores of the most common simulants, *B. g.* and *B. subtilis*.
- *B. anthracis* spores are similar in size to *B. cereus* and *B. megaterium*.
- Spores of pathogenic and non-pathogenic *B. anthracis* are similar in size.



ECBC

Acknowledgements

MICROBIOLOGY TEAM

Leslie Williams

Warren Gardner

UNIVERSITY OF PENNSYLVANIA – BIOMEDICAL IMAGING CORE LABORATORY

Neelima Shah

Ray Meade



ECBC